

AltRider Adjustable Windscreen for Yamaha Tenéré 700 (2025+)

INSTALLATION & CARE INSTRUCTIONS



Dear Rider,

Thank you for choosing AltRider! Whether a seasoned world adventurer or a first time ADV-Newbie, we welcome you to the AltRider experience. You can install your new product with the upmost confidence. AltRider designs and rigorously tests every product we make, and we're proud to put our name behind it.

Enjoy it, show it off, and most of all, RIDE IT!

Venture On,
Jeremy LeBreton



Kit Contents

- | | |
|----------------------------------|----------------------------|
| ① AltRider Adjustable Windscreen | ⑥ Nylon Washers, Thick (4) |
| ② Riser Bracket – Rider's Right | ⑦ Nylon Washers, Thin (4) |
| ③ Riser Bracket – Rider's Left | ⑧ Flat Head Screws (6) |
| ④ Riser Spacers (2) | ⑨ Hex Cap Screws (4) |
| ⑤ Knurled Adjustment Nuts (4) | |



Tools necessary:

- ① 1/4" driver handle (or any allen key set)
- ② M3 Allen (hex)
- ③ M4 Allen (hex)



1



Remove the OEM windscreen

Using an Allen key, remove the OEM windscreen screws starting from the bottom up to avoid scratching the fairing. Set the OEM hardware aside in case you resell the bike, and retain the small washer under each screw head along with the rubber boots.

2



Position the riser brackets

The bracket with the AltRider logo mounts on the rider's left side; the unmarked bracket mounts on the rider's right. On both sides, the rounded (radius) end of the bracket faces down.

3



Secure the riser brackets

Start a fastener by hand on each side so the bracket can pivot out of the way. Slide the hex cap screw into the bracket's slot and down to the bottom, then swing the bracket back into position over it. Install the final fastener on each side to secure the bracket in place.

4



Fit the thick washers

Slide the thick nylon washers onto the mounting bolts first. These sit underneath the windscreen to lift it off the riser bracket. Keep the bolts in their lowest position for now.

5



Mount the windscreen

Position the windscreen over the four mounting posts, flexing it gently as needed to align all four holes. Slide the thin nylon washers on top of the windscreen, over the same bolts.

6



Apply thread locker

Apply a small amount of serviceable thread locker to each knurled nut's threads, starting from the nut side to avoid getting any on the windscreen. Wipe away any excess before it sets.

7



Install the knurled nuts

Thread the knurled adjustment nuts onto the bottom fasteners by hand until snug. They thread onto a rubber-compression fitting under tension, so do not over tighten.

8



Adjust to ride

For off-road riding, run the screen in its lowest position. For highway riding, turn each knurled nut about one full revolution to raise the screen, then snug back down.

CONGRATULATIONS!

You've completed your installation. If at any point you have questions about your installation or have any feedback for us, we'd love to hear it. A downloadable version of these instructions can be found at our website. www.AltRider.com

Global Office:

email: info@altrider.com
phone: +1 206-922-3618
address: 3708 Airport Way South
Seattle, WA 98134

